



Four Stroke Works
15454 El Centro road
Hesperia, Ca. 92345
760-948-0325
www.fourstrokeworks.com

Installation tips for the FSW Quiet tip insert.



- ✓ Check fitment without o-ring and drill fastening hole towards rear tire approximately at 9 o'clock
- ✓ The O-Rings used for the FSW Quiet tip can be replaced using a XR600r Valve tappet cover o-ring if needed, please check your local shop for availability
- ✓ Always clean and lube spigot outlet lightly before stabbing in FSW quiet tip
- ✓ Do not pull out the FSW Quiet tip with pliers. If needed, remove muffler outlet and push FSW Quiet tip out. Now would also be a good time to check the screen and muffler packing.
- ✓ This tip can be modified for other pipes. Please contact us for details

